



APPLICATION GUIDE

SMART MULTIFUNCTION WALLCOVERINGS

Smart 2 in 1 Wallcovering Magnetic Dry Erase

Smart 3 in 1 Wallcovering Magnetic, Dry Erase and Projection

Use care when handling your Smart Magnetic Multifunction Wallcoverings. Ensure you do not crease or fold over the material as you may damage the surface. We recommend that you wear gloves.

1

PREPARE THE SURFACE

- Cover the floor with plastic or other suitable protection material.
- Check and fill any holes or cracks in the surface with a normal decorators filler.
- Remove all previous wallcoverings or old / loose paint.
- Use abrasive paper to sand smooth and rough or uneven surfaces.
- Absorbent surfaces should be treated with a primer, such as Smart White Primer, before the application of your Smart Multifunction Wallcovering.

2

MEASURE & MARK

- We recommend horizontal application of the wallcovering, starting with the bottom section of the wall.
- With a pencil, mark a straight, level and horizontal line across the wall, 1.22cm off the floor. This will guide the top edge of the first section of wallcovering.
- Measure the wallcovering to the desired length and cut with a sharp blade or sharp scissors.

3

APPLY THE ADHESIVE

- A Vinyl over Vinyl adhesive is required to install Smart Magnetic 2in1 / 3in1 Wallcovering. Standard wallcovering adhesives are not suitable.
- Stir the adhesive before use. If the adhesive is very thick or viscous, add upto 2.5% - 5% water until it's smooth.
- Apply one generous coat of vinyl over vinyl adhesive to the wall with a roller and brush for the edges. Do not overapply the adhesive.

4

INSTALLATION

First length of material:

- Starting in a corner, install the bottom section first, roll the wallcovering out along the wall, use your pencil line at 1.22cm as a guide.
- Carefully roll out the wallcovering along the wall pushing any air and excess adhesive out from behind the material as you go.
- Using a wallcovering spatula, press the entire surface of the wallcovering to the wall, pushing out all the excess wallcovering adhesive from behind the material.
- Use a consistent and strong pressure to ensure all air bubbles and excess adhesive have been pushed out to the edges.

Next length of material:

- For jointing the material, we recommend you butt the material together. The material is supplied with clean straight edges which will meet evenly.
- It is important to hang the lower section first so the section applied above will naturally sit on the lower section.
- The material will meet and can be worked together with a wallcovering spatula. Work the material by applying upwards and downwards pressure to each section along the joint bringing them together.
- If an area of the joint requires additional attention, add extra adhesive and continue to work together.
- If the joint / seam is not flat, gently lift the edge of one section of the wallcovering off the wall and guide the material to slot together and work again with spatula. You may need to add a small amount of extra adhesive.
- Check the entire surface of the wallcovering for any excess adhesive or air pockets and push out to an edge with a spatula.
- Repeat this process for the entire installation of the wallcovering.
- Once wallcovering installation is complete, wipe the entire surface clean with a damp cloth to remove any excess adhesive residue. Finally inspect for any air bubbles.

Note

You can overlap and double cut the material if required. Cut the material at angles such as a 90 degree wall corner.

5

ALLOW TO DRY

Smart Multifunction Wallcoverings should not be used for 48 hours following installation to allow adhesive to fully dry.

Product Liability Clause

The sale of our products is subject to our General Terms and Conditions available on www.smartersurfaces.com

Using your Smarter Surface

- For best results, we recommend using high quality accessories, such as those available on our website or from your local Smarter Surfaces partner.
- Clean on a regular basis with a microfibre cloth and our cleaning fluids as required.
- Use neodymium magnets such as Smart Neo-Magnets on magnetic wallcoverings.



Support:

Email:
support@smartersurfaces.com

Phone (Ire):
+353 1 412 6200

Website:
www.smartersurfaces.com